

TYPE 2 OBJECT MARKERS:
ERECT ONE AT BEGINNING AND END OF THE TAPER.
SPACE OTHERS 2 FEET Laterally. MARKERS
SHOULD BE 3 FEET OFF PAVEMENT EDGE OR AT THE
SHOULDER POINT FOR STABILIZED SHOULDERS.

SEE EPG 903.17 FOR USE OF TYPE 2 OBJECT
MARKERS ON CLIMBING LANES.

